




Roof Renewal System Details

Support (Newly Installed or Movable)



Pre-Application:

Lift existing blocks. Install two layers of new modified bitumen (acting as buffers)

The first layer to extend 6 inches beyond the block

The Second layer to extend 2 inches beyond the block (Second Layer is used as buffer only)

Application:

Install new roof renewal system over the first modified bitumen membrane, encapsulating the first layer of the modified bitumen.

